

EPSON PRODUCT SUPPORT BULLETIN

Date: 9/07/2001

PSB No.: 2001.08.002

Reference: TE01-045 Rev. B

Originator: TC & JD

Authorization: 

Affected Product(s): EPSON Imaging Products (Scanners, Digital Cameras, and Stylus Scan Devices)

Subject: Compatibility Chart for Macintosh OS X Classic

This bulletin provides information on compatibility for EPSON Scanners, Digital Cameras, and Stylus Scan Series devices running in Macintosh OS X Classic mode. Mac OS X provides the Classic environment mode for Mac OS 9 compatible applications and device drivers. Classic mode will require Mac OS 9.1 system software. To setup Classic mode follow the steps below:

1. First install or upgrade your Macintosh system to OS 9.1 before installing OS X (for details refer to Apple's OS X documentation).
2. To start in Classic mode, click the **Classic** icon in System Preferences. To find *System Preferences* go to the **Apple Menu** or click on the icon in the **Dock** bar on the desktop. Classic mode can also be set up to start automatically during the log in process. (Refer to your Apple documentation for installation and operation of Macintosh OS X Classic and 9.1).
3. To run a Classic application, just double-click on it or a document created with the application.

A) The following Epson models are supported in OS X Classic mode via USB.

| Model | Driver Version | Connector Type |
|-------------------------|---------------------------------------|----------------|
| Perfection 610 | TWAIN L 1.00E | USB |
| Perfection 636U | TWAIN 3.20A | USB |
| Perfection 640U | TWAIN L 2.01A | USB |
| Perfection 1200U | TWAIN 4.01A | USB |
| Perfection 1240U | TWAIN 5.00A | USB |
| Perfection 1640SU | TWAIN 5.00A | USB |
| Expression 1600 | TWAIN Pro/Pro Network 2.00A * | USB |
| Expression 1640XL | TWAIN Pro/Pro Network 2.00A * | USB |
| Expression 1680 | TWAIN Pro/Pro Network 2.00A * | USB |
| Stylus Scan 2000 | TWAIN (v.1.10A); Printer (v.6.25E) ** | USB |
| Stylus Scan 2500 | TWAIN (v.1.10A); Printer (v.6.25E) ** | USB |
| Photo PC 800/850Z/3000Z | EPSON Photo!3 (v.1.40E) *** | USB |
| Photo PC 3100Z | USB Storage Device **** | USB |

Note: MAC OS X Classic mode supports USB-native and network-capable devices. Classic mode does not support MAC Serial, SCSI or FireWire connected devices.

* Expression Series Scanner Notes:

1. When installing the TWAIN driver and you are prompted to restart your computer, click Quit instead.
2. Click Stop to close the Classic environment. Close the System Preferences folder. Then restart the computer.
3. If you install PageManager v 2.40.05 for the Expression series scanners and the Start button does not work, restart the computer.

**** Stylus Scan Notes:**

1. You must install the Stylus Scan drivers in a true 9.1 environment. Do not install in OS X Classic, the installation will hang. From the Printing and Scanning Software CD, open the Epson Stylus Scan 2xxx folder and click on the icon to install the drivers. When prompted, restart the computer. Make sure the startup disk is set to OS X before restarting. Start Classic and install Smart Panel.
2. You must install Smart Panel from its own folder. From the Software CD open the Smart Panel folder. Click on the Epson Smart Panel Installer icon to install. Before you can launch Smart Panel you must install the Stylus Scan Updater. The file can be downloaded from the Epson web site.

***** Digital Camera Notes:**

1. EPSON Photo! 3 must be installed in a true Mac OS 9.1 environment. It cannot be installed in Mac OS X Classic mode. After installation, restart the computer in OS X, start Classic, then launch Photo! 3.
2. Use the EPSON *Camera Monitor Setup* dialog box in *Apple Menu Items* to assign an application before using the programmable *Push (Shutter) Button Function*.
3. You can use the *Push Button Function* in Classic mode.

******Photo PC 3100Z Notes:**

1. This camera is supported by Mac OS X native mode using the embedded Image Capture application.

B) The following models are not supported in OS X Classic when using the connector type(s) described in the chart below.

| Model | Connector Type |
|------------------------------|----------------|
| Perfection 636 | SCSI |
| Perfection 1200 | SCSI |
| Expression 636 | SCSI |
| Expression 800 | SCSI |
| Expression 1600 | SCSI/FireWire |
| Expression 1640XL | SCSI/FireWire |
| Expression 1680 | SCSI/FireWire |
| Expression 836XL | SCSI |
| GT-10000 (PC platform only) | SCSI |
| GT-10000+ (PC platform only) | SCSI |
| GT-30000 (PC platform only) | SCSI/FireWire |
| Photo PC 500 | Serial |
| Photo PC 600 | Serial |
| Photo PC 650 | Serial |
| Photo PC 700 | Serial |
| Photo PC 750Z | Serial |

EPSON PRODUCT SUPPORT BULLETIN

Date: 11/12/1999
PSB #: PSB.1999.11.001A
Reference: N/A
Product(s): PhotoPC 850Z
Subject: Optional Accessories

Originator: DS
Authorization: *Kps*
Total Pages: 1

This document provides source information on the Optional Accessories for the Epson PhotoPC-850Z Digital Camera.

Epson Accessories (800) 873-7766 or [HTTP://supplies.epson.com](http://supplies.epson.com)

| | |
|--------------------------------|---------|
| Universal AC adapter | B867081 |
| EPSON Universal NiMH Power Pak | B818172 |
| EPSON NiMH Battery Pak | B818113 |

Third Party Accessories

> Metz 32 Z-2 Flash

This is the official Epson recommended flash for the PhotoPC 850Z. The Metz Flash can be ordered from Smile Photo at 1-212-967-5900 or other leading camera shops. There may be other flash units available through camera stores that should be compatible, however, Epson has not tested them with the PhotoPC 850Z and therefore cannot recommend.

> Lenses and Filters

Tiffen lenses are available through DC PRO 1-800-522-7835. They offer telephoto and wide-angle converter lenses, as well as various filters. Epson has tested these Tiffen lenses and filters and they work with the PhotoPC 850Z. There is a 49mm thread on the lens adapter for the PhotoPC 850Z. You can also purchase lenses with 49mm threads at leading camera stores.